Product code □□□ **BS** □ □ **1** □ □ □ □□□□ - □□

① ② ③ ④ ⑤ ⑥ ⑦ ⑧ ⑨ ⑩

Code configuration (The contents are described in the specifications.)

①Actuator model / ②Valve model / ③Voltage / ④Sizing / ⑤Connection
⑥Body material / ⑦Ball material / ⑧Seat material / ⑨Size / ⑩Option

Type	Category	①Actuator model		③Voltage		⑨Size(A)	-015	-020	-025	-032		-040		-050		-065	-080 R100		R125		R150	
						④Sizing	0	0	0	1	0	0	2	0	2	0	0	2	0	2	1	0
ON-OFF	Compact	**AM1**	Transfer input	**1**	100/110V AC		070		180													
				2	200/220V AC																	
		AM2	a-contact input	**1**	100/110V AC		070		180													
				2	200/220V AC																	
		AH1	Transfer input	**1**	100/110V AC		070		180													
				2	200/220V AC																	
		DM2	a-contact input	**0**	24V DC		070		180													
		DM0	Switching polarity	**0**	24V DC		070		180													
	Economy	**AE1**	Transfer input	**1**	100/110V AC		120				360			360		700			02K		02K	06K
				2	200/220V AC																	
		AE2	a-contact input	**1**	100/110V AC		120				360			360		700			02K		02K	06K
				2	200/220V AC																	
				0	24V DC		120				360			360								
	Standard	**AD1**	Transfer input	**1**	100/110V AC				300		300		700			700						
				2	200/220V AC																	
		AD2	a-contact input	**1**	100/110V AC				300		300		700			700						
				2	200/220V AC																	
				0	24V DC																	
				7	115/120V AC																	
				8	230/240V AC																	
		AD0	Switching polarity	**0**	24V DC				300		300		700			700						
		HD1	Transfer input	**1**	100/110V AC				300		300		700			700			02K		02K	06K
				2	200/220V AC																	
		HD2	a-contact input	**1**	100/110V AC				300		300		700			700			02K		02K	06K
				2	200/220V AC																	
				0	24V DC																	
		HD0	Switching polarity	**0**	24V DC				300		300		700			700			02K		02K	06K

Type	Category	①Actuator model		③Voltage		⑨Size(A)	-015	-020	-025	-032		-040		-050		-065	-080 R100		R125		R150	
						④Sizing	0	0	0	1	0	0	2	0	2	0	0	2	0	2	1	0
Emergency	Economy	**ECR**	a-contact input Power ON / OFF	**1**	100/110V AC		120				360			360								
				2	200/220V AC																	
	Standard	**ABR**	a-contact input Power ON / OFF	**1**	100/110V AC				300		300		700			700						
				2	200/220V AC																	
				0	24V DC																	
		HBR	a-contact input Power ON / OFF	**1**	100/110V AC				300		300		700			700			02K		02K	06K
				2	200/220V AC																	
				0	24V DC																	