

型式： □□□ Z- □ □ □ T □ □ □ - □□□□ - □□□
 ① ② ③ ④ ⑤ ⑥ ⑦ ⑧ ⑨ ⑩

コード構成 (内容は仕様書で確認してください。)

①操作機型式 / ②バルブ型式 / ③電源電圧 / ④ランク / ⑤接続規格
 ⑥本体材質 / ⑦キャップ材質 / ⑧シート材質 / ⑨呼び径 / ⑩オプション

| 制御 | タイプ | ①操作機型式 | | ③電源電圧 | | ⑨呼び径 (A) | | 015 | | 020 | | 025 | | 032 | | 040 | 050 | |
|--------|------------|----------------|------------------------|------------|------------|----------|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|--|
| | | | | | | ④ランク | 0 | 2 | 0 | 2 | 0 | 2 | 0 | 2 | 0 | 0 | | |
| ON-OFF | ミニ | CA1 | 超小形・エコノミーモデル 電源振替入力 | 1 | AC100V | 015 | | 015 | | | | | | | | | | |
| | | | | 2 | AC200V | | | | | | | | | | | | | |
| | | PM1 | 無接点電子制御 a接点信号入力 | 1 | AC100/110V | 030 | | 030 | | 030 | | 030 | | 030 | | | | |
| | | | | 2 | AC200/220V | | | | | | | | | | | | | |
| | | CM1 | 電源振替入力 | 1 | AC100/110V | 030 | | 030 | | 030 | | 030 | | 030 | | 070 | | |
| | | | | 2 | AC200/220V | | | | | | | | | | | | | |
| | | CM2 | a接点信号入力 | 1 | AC100/110V | 030 | | 030 | | 030 | | 030 | | 030 | | 070 | | |
| | | | | 2 | AC200/220V | | | | | | | | | | | | | |
| | | CD2 | a接点信号入力 | 0 | DC24V | 030 | | 030 | | 030 | | 030 | | 030 | | 070 | | |
| | | | | 4 | DC12V | | | | | | | | | | | | | |
| | AM1 | 電源振替入力 | 1 | AC100/110V | 030 | | 030 | | 030 | | 030 | | 030 | | 070 | | | |
| | | | 2 | AC200/220V | | | | | | | | | | | | | | |
| | AM2 | a接点信号入力 | 1 | AC100/110V | 030 | | 030 | | 030 | | 030 | | 030 | | 070 | | | |
| | | | 2 | AC200/220V | | | | | | | | | | | | | | |
| | AH1 | 高速作動 電源振替入力 | 1 | AC100/110V | 030 | 070 | 030 | 070 | 030 | 070 | 030 | | 030 | | 070 | | | |
| | | | 2 | AC200/220V | | | | | | | | | | | | | | |
| | DM2 | a接点信号入力 | 0 | DC24V | 030 | 070 | 030 | 070 | 030 | 070 | 030 | | 030 | | 070 | | | |
| | | | 0 | DC24V | | | | | | | | | | | | | | |
| DM0 | 極性反転入力 | 0 | DC24V | 030 | 070 | 030 | 070 | 030 | 070 | 030 | | 030 | | 070 | | | | |
| | | 0 | DC24V | | | | | | | | | | | | | | | |
| エコノミー | AE1 | 電源振替入力 | 1 | AC100/110V | 120 | | | 120 | | 120 | | 120 | | 120 | | | | |
| | | | 2 | AC200/220V | | | | | | | | | | | | | | |
| | AE2 | a接点信号入力 | 1 | AC100/110V | 120 | | | 120 | | 120 | | 120 | | 120 | | | | |
| | | | 2 | AC200/220V | | | | | | | | | | | | | | |
| 0 | DC24V | 120 | | | 120 | | 120 | | 120 | | 120 | | 120 | | | | | |
| 比例制御 | ミニ | CMX | 4~20mA | 1 | AC100/110V | 030 | | 030 | | 030 | | 030 | | 070 | | | | |
| | | | | 2 | AC200/220V | | | | | | | | | | | | | |
| | | | | 0 | DC24V | 015 | | | 015 | | 070 | | 070 | | | | | |
| | コンパクト | PAX | 4~20mA・1~5V | 1 | AC100/110V | 050 | | | 050 | | 050 | | 050 | | 120 | | | |
| | | | | 2 | AC200/220V | | | | | | | | | | | | | |
| | エコノミー | AEX | 4~20mA・1~5V 抵抗入力、他 | 1 | AC100/110V | 120 | | | 120 | | 120 | | 120 | | 120 | | | |
| | | | | 2 | AC200/220V | | | | | | | | | | | | | |
| | | PEX | 高速作動 4~20mA・1~5V | 6 | AC100~240V | 120 | | | 120 | | 120 | | 120 | | 120 | | | |
| 0 | DC24V | | | | | | | | | | | | | | | | | |
| 制御 | タイプ | ①操作機型式 | | ③電源電圧 | | ⑨呼び径 (A) | | 015 | | 020 | | 025 | | 032 | | 040 | 050 | |
| | | | | | | ④ランク | 0 | 2 | 0 | 2 | 0 | 2 | 0 | 2 | 0 | 0 | | |
| 無線リモコン | コンパクト | RAM | リモコン操作 | 1 | AC100/110V | 030 | | 030 | | 030 | | 030 | | 070 | | | | |
| | | | | 2 | AC200/220V | | | | | | | | | | | | | |
| 緊急遮断 | コンパクト | ACR | 電源喪失で緊急作動 | 2 | AC100~220V | 030 | | 030 | | 030 | | 030 | | | | | | |
| | エコノミー | ECR | a接点信号入力 電源喪失で緊急作動 | 1 | AC100/110V | 120 | | 120 | | 120 | | 120 | | 120 | | | | |
| 2 | AC200/220V | | | | | | | | | | | | | | | | | |